

Mounting Instructions

The hardware provided is for use on hollow walls. If you are hanging onto another wall surface, consult your hardware professional for advice on the proper hardware to use.

To mount:

1. Keyholes can be found on the back of the largest section of the wall shelf. Hang this section before assembling entire unit.
2. Measure distance between center points of each keyhole.
3. It is advisable to use an awl to punch a small hole the size of the anchors' point in the drywall. Providing this starter hole will give you a more accurate installation.
4. Screw the plastic anchor into the drywall with a Philip's head screwdriver until the head is flat against the wall surface. The surface of the drywall may distort, tear or slightly "buckle" as the anchor is installed... this is perfectly normal and to be expected.
5. Screw the screw into the anchor.
6. Hang the largest section securely on the wall, then insert the other sections into the slots provided to assemble as shown on the box.

Anchors are rated for up to 15 lbs total weight (shelf weight is 6 lbs).

THE POMEROY COLLECTION, LTD.
4820 Blalock #101 • Houston, Texas 77041 • www.pomeroycollection.com •
Toll Free Fax: (877) POMEROY