

Assembly Instructions-Teagan Wall Teester

1. Remove teester (A), curtain rail (B), and fastener baggie from box.
2. Locate the two mounting brackets on the back of the teester (A).

If attaching teester directly to a wooden stud:

3. Slide a brass washer (D) onto each of the screws (C). Attach the teester to the wall by drilling screws through the pair of holes on each mounting bracket.

OR

If attaching teester to drywall:

3. Carefully measure the distances between the two pairs of holes on the mounting bracket. Make four marks corresponding to those exact distances at the desired hanging point on your wall; use a straightedge to ensure horizontal alignment of the holes.







Pre-drill a hole through each mark on the wall. Fully hammer a plastic drywall anchor (E) into each hole.

Slide a brass washer (D) onto each of the screws (C). Attach the teester to the wall by drilling screws through the pair of holes on each mounting bracket and into the plastic drywall anchors (E).

4. (optional) Cover each screw head with a brass cap (F) by screwing the caps onto the threading of the brass washers (D).
5. Attach your curtain panels, valance, or scarf as desired to the curtain rail (B). Attach the curtain rail to the back of the teester by inserting the prongs on each end of the curtain rail to the vertical sockets on each teester mounting bracket.

Your teester is now ready for use!

Parts Required

A		1pc.	D		4pcs.
B		1pc.	E		4pcs.
C		4pcs.	F		4pcs.

