

- 1.)** Locate the two scrollwork side panels. Identify the 3 bolt holes at each top and 2 bolt holes at each bottom.
- 2.)** Attach the bottom shelf to the side rails. Do not tighten bolts.
- 3.)** Attach the three hanging rods to the top of the side rails.
Tighten all bolts.
- 4.)** Your towel rack is now ready for use.