



Setup Instructions

1. Insert the Rod into the left side of the holder.
2. Then slide the right side of the rod into the slot from behind.

Please note: Check the bottom of the Styrofoam packaging for the rod.