

# Assembly Instructions

## **CATION:**

Read instructions carefully and turn electricity off at main circuit breaker panel before beginning installation

## **WARNING**

All wires are connected. When unpack box, be careful not pull wires, As a bad connection may result in. Do not connect electricity until lamp is fully

Assembled Unpack and place all parts on a surface or floor

## **ASSEMBLY INSTRUCTIONS:**

- 1) Place the lamp on a level surface.
- 2) Screw Threaded Rod into the Socket assembly.
- 3) Screw Knurl Nut on Threaded Rod. This can be used to raise the Shade a little if necessary.
- 4) Place the Shade over the end of the Threaded Rod and screw the Finial securing the shade in place.
- 5) Insert bulbs( not included) into the bulb socket.

**Recommended (2) 60-watt standard base on/off bulbs or (2) 10-watt standard base LED bulbs (Bulbs not included).**

## **Important Safety Instructions:**

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter the plug.

