

# GARDEN WEATHERVANE INSTRUCTIONS

## Your Weathervane Consists of:

- A. Mast sections without pin
- B. Mast section with pin
- C. Ornament
- D. Directional support ring with set screw
- E. East and West directional
- F. North and South directional with set screw

## To Assemble:

1. Push mast section (A) into soil of desired location until top of pin is level with ground.
2. Slide together the 2 mast sections (A & B) with pin located at top.
3. Insert the assembled mast sections into first section.

*(NOTE mast must be perfectly vertical for weathervane to function properly. Adjust if necessary and tamp soil around mast)*

4. Attach directional support ring (E) by sliding it over the mast. Locate 12" down from top of mast and tighten the set screw.
5. Slide East /West (E) directional over the mast so that the bottom rests on the support ring.
6. Slide North/South directional (F) over mast until it interlocks with the east/west directional. Rotate the directional assembly until the "N" is pointing north and secure the set screw. **Do not over tighten!**
7. Set ornament (C) onto pin.

Your Garden Weathervane is now assembled and ready for a lifetime of enjoyment.

Cleaning your weathervane should be accomplished using water and a soft rag. Do not use harsh detergents or abrasives as this may damage the painted finish.

