

# Assembly Instructions

## CAUTION

Read instructions carefully and turn electricity off at main circuit breaker panel before beginning installation.

## WARNING



All wires are connected. When unpacking box, be careful not to pull wires, As a bad connection may result. Do not connect electricity until lamp is fully assembled. Unpack and place all parts on a flat surface or floor.

## ASSEMBLY INSTRUCTIONS:

- 1) Place the lamp on a level surface.
- 2) Screw Threaded Rod into the Socket assembly.
- 3) Place the Shade over the end of the Threaded Rod and screw the Finial securing the shade in place.
- 4) Insert bulbs into the bulb sockets.

**Recommended (2) 13-watt to 15-watt standard base CFL Bulbs.(13-watt CFL bulb included)**

## Important Safety Instructions:

-  This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician.
-  Never use with an extension cord unless the plug can be fully inserted.

