

# Assembly Instructions

## WARNING

All wires are connected. When unpacking box, be careful not to pull wires. As a bad connection may result. Do not connect electricity until lamp is fully assembled. Unpack and place all parts on a surface or floor

## ASSEMBLY INSTRUCTIONS:

- 1) Place the lamp on a level surface.
- 2) Unscrew the Screw on the bottom of the base
- 3) From the Base take out E12 socket, install the candelabra base bulb into E12 socket, and replace it by tightening the wing nut on the end of the Rod.
- 4) Screw Threaded Rod into the Socket assembly.
- 5) Put the Washer onto the Threaded Rod.
- 6) Place the Shade over the end of the Threaded Rod and screw the Finial securing the shade in place.
- 7) Insert bulb (15watt CFL bulb not included) into the bulb socket.



## Important Safety Instructions:

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted.

