

Abbott Accent Table

Assembly Instructions

NOTE: We recommend not using power tools to assemble.

STEP 1: Invert C-table top onto a clean, smooth surface.

STEP 2: NOTE: All hardware pieces are located inside of the drawer for storage during shipping. Attach each A-leg to the top using 1 F-short bolt. Do not tighten completely.

STEP 3: Attach D-shelf to bottom of A-legs matching the dowel holes.

NOTE: You may have to pull slightly on the legs to get the dowels lined up so that the shelf is seated.

STEP 4: Attach each B-leg to the bottom of D-shelf using a J-long bolt. This bolt goes through the B-leg and the D-shelf by threading in the bottom of the A-leg.

NOTE: You may need to move the A-leg slightly and hold it in place as you screw in the bolt to make sure it goes into the threading. Do not tighten completely.

STEP 5: Put the E-bottom drawer shelf onto B-legs matching the dowels to hold it in place. Take the drawer out of the shelf and insert and F-short screw through the shelf and into the threading on the bottom of the B-legs. Again, you may have to move the legs slightly to get the bolts into the threading. These can be fastened securely.

STEP 6: Go back and tighten all bolts then turn the table upright.

