

# ASSEMBLY INSTRUCTIONS

1. FASTEN SOCKET ASSEMBLY ONTO LAMP BODY.
2. PLACE THE HARP ONTO SADDLE.
3. PLACE THE SHADE ONTO HARP AND TIGHTEN FINIAL.

## IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

**READ & SAVE THESE INSTRUCTIONS**

