










**Assembly Instructions**  
**ITEM NO.: D80757-EP**

**Parts Required**

A		1pc	D		4pcs
B		4pcs	E		4pcs
C		1pc	F		12pcs



- 1.) Carefully remove all parts from the carton.
- 2.) Attach the metal crosspiece (C) to the lower portion of each leg (B) using one washer (D) and one screw (E) each.
- 3.) Attach each leg (B) to the apron of the table top (A) using three wood screws (F). Attach by drilling two wood screws through the back of the apron and one wood screw up through the bottom of the apron.
- 4.) Accent table is now ready for use.