


# Bath Time Water Fountain

**Jebao**<sup>®</sup>  
捷寶

SUBMERSIBLE PUMP

## OWNER'S MANUAL

**Jebao** pumps are carefully tested and certified to ensure both safety and operating performance. Failure to follow the instructions and warnings in this manual may result in pump damage and/or serious injury. Be sure to read, thoroughly understand, and save this manual for future reference.



Jebao Electrical Appliances Co., Ltd.  
Tongmao Industrial Park, Dongsheng,  
Zhongshan, Guangdong china  
E-mail: info@jebao.com  
Website: www.jebao.com  
Tel: +86-760-22212306, 22212307  
Fax: +86-760-22212368

## INSTRUCTIONS

1. Only the pump and the electrical cord directly connecting the two are to come in contact with water. Under no circumstances should the other parts come into contact with water.
2. Do not plug-in or otherwise use this product if any part of it appears to be damaged or operates abnormally. Have the product examined and repaired, if necessary, by a qualified electrician.
3. Make a "drip loop" on the electrical cord connecting the pump to the plug by letting a portion of the cord hang lower than either the pump or the plug.
4. Do not let the pump run when not submerged in water. Doing so may damage the pump. Always submerge the pump first, and then plug in the unit. At the beginning, it probably can't pump water, because there is air in the pump and the tube. Don't worry about it. Please pull out and insert electrical outlet several times, it will work very well at once.
5. Take care to ensure excess power cords are stowed so as to avoid tripping.
6. Operate the unit only under constant adult supervision and monitoring. Keep the unit unplugged when not under direct observation.
7. Use this product indoors only.

## MAINTENANCE

1. Use this pump with distilled water only. Mineral build up from tap water, or water from other sources, can ruin the pump.
2. No maintenance is necessary when this product is used in the manner described in this manual.
3. If debris is caught in the intake vents of the pump, disconnect the pump from any power sources and rinse the pump under clean running water.

# RELAXATION FOUNTAN

## PRODUCT INSTRUCTION MANUAL

Thank you for purchasing this creative water fountain product.  
Please read this manual before operating it.

### Table of Contents

Introduction .....	1
Important Safety Instruction .....	2-3
Assembly and Instructions for Use .....	4-5
Assembly Illustrations .....	6-8
Troubleshooting Guide .....	9
Cleaning and Maintenance .....	10
Conclusion .....	11

## Introduction

Thank you for purchasing this Water Fountain product. You have purchased a product that complies with the latest design and with a creative theme.

This product is carefully packaged, inspected and tested to insure safe operation and delivery. The following illustrations, instructions and safety guidelines will enable you to use the product for trouble-free operation.

Please read the instructions and safety guidelines entirely before using the product and match the item to the appropriate illustrations showing below.

-1-

## IMPORTANT SAFETY INSTRUCTIONS:

When using an electrical appliance, basic precautions should always be followed, including the following:

### READ ALL INSTRUCTIONS BEFORE USING

#### To reduce the risk of electric shock:

- \* Always unplug the appliance from the electrical outlet immediately after using and before cleaning.
- \* Do not reach for an appliance that has fallen into water. Unplug it immediately.
- \* Do not place or store appliance where it can fall or be pulled into a tub or sink. Do not place in or drop into water or other liquid.
- \* Do not connect to any voltage other than that shown on the pump.

#### To reduce the risk of shock or injury to person:

- \* Never leave the appliance unattended, especially if children are present
- \* Never cover the appliance when it is in operation.
- \* This unit should not be used by children without adult supervision.
- \* In case of damage caused, please be ensure to put the *Slim Iron Wire* (If supplied) away from children, do not let the pump with it.
- \* Connect the pump with the proper voltage as indicated on the pump label.

-2-

- \*Always keep the cord away from high temperature and fire.
- \*Unplug the pump from power source before cleaning maintenance or disassembling.
- \*To get the best flowing effect, product must be placed on a flat surface and should never be placed on an electrical appliance.
- \*Never operate this appliance if it has a damaged cord, plug, pump, cable or housing.
- \*Never let pump run dry, as this will shorten the life of the pump.
- \*Do not lift, carry, hang, or pull the pump by the power cord.
- \*To disconnect, remove plug from outlet.
- \*Operate with tap water or distilled water only, and replace it frequently.
- \*Operate pump completely submerged for proper cooling.
- \*Disconnect the appliance from electrical outlet before putting hands into water.

**CAUTION:**

The pump must be completely submerged in water. If the pump is making noises, most likely it is not completely submerged in water.

Check the water level, check the circuit breaker.

Keep the water clean, prevent the water from becoming sticky and forming micro-organisms

Clean:

Clean the container in a mixture of vinegar and water to clean and remove any mineral build-up.

**Assembly and Instructions for Use**

*Before starting please match your item to Assembly Illustrations*

1. Unpack the product, remove plastic bag from packaging. Wipe off dust with a damp cloth in the base and inside of the base.
2. Place the product on a flat surface, for tabletop items please cover a soft cloth in case of the damage caused by the humidity.
3. Familiarize yourself with the pump (Please read pump instruction first). The pump speed is controlled by the switch located at the front of the pump. The speed is indicated by a plus (+) and minus (-) sign. To increase the speed, move to each speed level. At this highest speed level, the switch will cease to move any further, vice versa. Note: it is recommended the pump be set at its highest speed during assembly and later adjusted to a lower setting if desired. Be sure to unplug the pump before adjusting the speed setting.
4. Lead the cord through the cord slot between the base and the platform. Ensure the platform is set level on the base. This will ensure that the unit is balanced when placed on a flat surface. Attach the A/C adaptor

jack to the base power cord. Do not plug into outlet at this time.

5. Insert the tube on the bottom side of the fountain into the pump. Make sure the tube is properly connected and does not crimp.

6. Set the fountain top onto the platform so it sits level.

7. Fill base with tap water to 1/2\*\*from top. We recommend using distilled water to prevent mineral build up. (No matter the size of the vessel base, the water should be higher than the pump and approximately 0.5cm below the lowest edge of the base.)

8. Connect the power cable leading from the product unit to the power cable of the transformer unit. (If without transformer item please follow below).


9. Plug the transformer unit into the power socket. If installed properly, water will come out of the spraying nozzle immediately. (If without transformer item please connect the power cable plug into the power socket directly)

**Please note:** On first use, there may be air in the pump. It can take up to a few minutes until the air escapes.

-5-

### Assembly Illustrations

Figure 1-Fountain Base1



Fill with water higher than pump lower than the lowest edge  
Cord Slot

Fountain Base2

Fill with water higher than pump lower than the lowest edge






Figure 2\_Fountain Top Steps Fountain




Fountain Top  
Tube  
Insert tube into pump  
Light Jack Adaptor  
Pump

Figure 3 Fountain Top Crossing Fountain Spraying Nozzle




-6-

**Figure 4\_ Rolling ball Fountain top**



**Figure 5\_Singleness Front Face**




**Figure 5\_Singleness Back Face**





Fill with water higher than pump and lower than the lowest edge

-7-


**Figure 6a\_Cascading Fountain top**




**Figure 6b\_Cascading Fountain**



**Figure 7. Layer - Shape Fountain**



**B. Large rock waterfall fountain**



-8-

## Troubleshooting Guide

### Troubleshooting Guide

If the pump starts to lose power or fails to operate, check the following:

Check for the build up of sediment or scale in the bottom of the pump housing or in the water contained product.

Check the circuit breaker, or try a different outlet to make sure the pump is getting electrical power.

**If the spraying nozzle obstructs:**

please use tiny iron wire *slightly cross* that tiny hole. The spraying nozzle should only be cleaned with supplied *Slim iron wire*.

**NOTE:** Always disconnect from electrical outlet before handling the pump.

**If the pump gurgles or spews:**

Check the water level to make sure the pump has enough water to function.

**Obtaining a desired water level:**

Check the water level daily the first week to measure the rate of evaporation; refill with water as needed.

**If water is splashing outside the fountain:**

Adjust the flow control valve to a lower setting on the pump.

**If the tube comes off please insert in.**

**When the Roll ball stops rolling, please clean the Salver with soft brush.**

-9-

## Cleaning and Maintenance

### Cleaning and Maintenance

\*Periodically change water and clean the product according to the water condition. Keeping the water clean prevents the water from becoming sticky and forming micro-organisms. We recommend distilled water to prevent mineral build-up.

\*Be insure to check the build up of sediment or scale in the bottom of the pump housing or in the filter screen periodically. (Note: The filter screen should only be cleaned with **Soft Brush**)

\*Remove the impeller or any dirt and scale, which has built up and close the case back up.

\*Clean the container in a mixture of vinegar and water to clean and remove any mineral build-up.

\*Add water periodically to keep water level at an appropriate level and to avoid shortening the life of the pump. (Note: Never let the pump run dry.)

\*For Roll ball items, please clean the Salver with soft brush regularly.

\*Unplug the fountain from the electrical outlet, empty the water, and store in a dry, cool place.

### Attention:

In order to get best results, please operate pump completely submerged

-10-

## *Conclusion*

These instructions relate to the water fountain product and contain important information for using the product for the first time. Please keep these instructions for later reference. They should always accompany the product in the event of transfer to a new user.

Thanks again for choosing this item. We hope it will help you create a relaxing, peaceful environment and bring you nature to your home, garden, or office, and making it easy to relax your mind, body and spirit.