

ASSEMBLY INSTRUCTIONS

TL18915

1. FASTEN THE SOCKET ASSEMBLY ONTO LAMP BODY.
BE CAREFUL NOT TO TWIST THE POWER CORD.
2. PLACE THE HARP ONTO SOCKET ASSEMBLY.
3. PLACE THE SHADE ONTO HARP AND TIGHTEN FINIAL.
4. FASTEN 1PC MAX 60W TYPE A BULB ONTO SOCKET.
(BULB NOT INCLUDED)

IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY INTO THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

