




#12254 Solar Vertical Wind Spinner - Flying Lotus ASSEMBLY INSTRUCTIONS

PART LIST:

				
A. 1PC	B. 1PC	C. 1PC	D. 1PC	E. 2PCS
				
F. 1PC	G. 1PC	H. 2PCS	I. 1PC	J. 1PC



WARNING: Do not leave out in high winds as it may damage the product.

Note: Before staking into the ground, make sure the ground is soft. If the ground is not soft, moisten the ground with water.



#12254 Solar Vertical Wind Spinner - Flying Lotus


The rechargeable battery may need to be replaced after a year of use. To replace the battery:

- Find and remove 2 inset screws on backside of solar panel. See diagram.

A. Remove this screw

B. Remove this screw

- Remove cover on the front of solar panel. Take out old battery and replace with a new NI-MH AAA 300 (or greater) mAh 1.2V rechargeable battery. Be sure to align polarity markings on the battery with those in battery housing.
- Replace cover aligning the screw holes with the posts and secure it with screws.



Install only new batteries of the same type. Failure to insert batteries in the correct polarity may shorten battery life or cause leakage. Do not dispose of batteries in fire. Recycle or dispose of batteries as per state or local guidelines.

Switch to the "OFF" position and remove batteries when storing for extended periods of time.



Battery must be recycled or disposed of properly. Do not short circuit or dispose of in fire.

