















Assembly Instructions

Palm Tree Wind Spinner

PART LIST

A		1PC
B		2PCS
C		16PCS
D		1PC
E		4PCS
F		4PCS
G		2PCS
H		1PC
I		1PC
J		1PC
K		1PC
L		1PC
M		1PC



WARNING: Do not leave out in high winds as it may damage the product.
Note: Before staking into the ground, make sure the ground is soft. If the ground is not soft, moisten the ground with water.