


## ASSEMBLY INSTRUCTIONS:


1. Carefully unpack parts from carton, remove covering from parts and check that all parts are included as shown in the illustration.
2. Secure the neck (D) on the body (E).
3. Place the shade(C) onto the socket of the neck (D) and secure with socket ring(B) until tightened.
4. Take out a LED light bulb (A) and operate the bulb brightness to suit your needs. (Please refer to the overleaf for the LED Bulb User's Guide. )
5. Install the light bulb(A) into the lamp socket of the neck (D) and enjoy your new outdoor lamp.

**USE A 5.6W (MAXIMUM) LED/BATTERY (INCLUDED)**



- ※ PLEASE INFORM YOUR DEALER IMMEDIATELY IN CASE OF ANY PARTS SHORTAGE.
- ※ SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

# LED Bulb User's Guide



1. Tap the touch switch, the first stage is 30% brightness (~180lm).
  2. Tap the touch switch again, the brightness will be increased to 100% (~600lm).
  3. Tap the touch switch again to power off the LED bulb.
- The LED bulb has an indicator light located on the bottom of the bulb.
  - Please refer to the table below for an explanation of the indicator light statuses.
  - When the bulb is connected to the charging cable and charging begins, it will automatically switch off and enter charging mode.

Bulb Mode	Status	Indicator Green Light	Indicator Red Light
Bulb ON	Full Battery	OFF	Bright
	Low Battery	OFF	Flashing
Charging Mode (Bulb Off + Plugged In)	Charging in process	Flashing	OFF
	Full Battery	Bright	OFF