Regal
ART & GIFT

14454 Vertical Wind Spinner - Americana

ASSEMBLY INSTRUCTIONS



A  1pc	B  1pc
C 1pc	D  1pc

WARNING:Do not leave out in high winds as it may damage the product.

Note: Before staking into the ground, make sure the ground is soft.
If the ground is not soft, moisten the ground with water.