






A  1pc	B  1pc	C lock washer  1pc	D  1pc
E  1pc	G  1pc		H  1pc
F  1pc			

WARNING: Do not leave out in high winds as it may damage the product.

Note: Before staking into the ground, make sure the ground is soft. If the ground is not soft, moisten the ground with water.