






A 1pc	B 2pc	C 1pc	D lock washer 1pc
E 1pc	F 1pc	G 1pc	
	F 1pc	H 1pc	



WARNING: Do not leave out in high winds as it may damage the product.

Note: Before staking into the ground, make sure the ground is soft. If the ground is not soft, moisten the ground with water.