

## Bellhurst Swivel Cane Back Dressing Chair


Examine all packaging material for small parts that may have come loose during shipment. Periodic checks are recommended to insure that all components are in proper position, tight and free from damage. Keep this assembly instruction for future reference. Adult assembly is required. The product of Hillsdale Furniture, LLC is designed for residential use only. Customer Service Phone Number: 502-562-0000

CODE	QTY	. HARDWARE	
1	8	1/4"*1-3/4" Allen Bolts	
2	8	1/4" Spring Washers	0
3	8	1/4"*15mm Flat Washers	0
4	1	Allen Wrench	

CODE	QTY	COMPONENTS	CODE	QTY	COMPONENTS
А	1	Chair Top	В	4	Legs


## AWARNING

- Do not let any sharp objects touch or rub the surface of the product.
- When assembling, do not let children play around the working area.
- Please confirm all parts are correct before starting the assembly process.
- Do not tighten all bolts and screws completely until the entire unit has been assembled and set up.
- Be careful if using power tools as they can over tighten screws and strip threads.



CARE & MAINTENANCE: The touch of a soft cloth is all the maintenance the finish will ever need. Please do not use harsh or abrasive cleaners for polishing, as they may cause damage to the finish. Periodic checks are recommended to make sure that all hardware is securely tightened.





Step 1

Begin assembly by attaching each Leg (B) to the Chair Top (A) using 2 Allen Bolts (1), 2 Spring Washers (2), 2 Flat Washers (3) per each leg. Tighten all bolts using the Allen Wrench (4). The assembly is now complete.