

# ASSEMBLY INSTRUCTIONS

## **CATUTION:**

**Read instructions carefully and turn electricity off at main circuit breaker panel before beginning installation**

## **WARNING:**

All wires are connected. When unpacking the box, be careful not to pull the wires as a bad connection may result. Do not connect to electricity until the lamp is fully assembled. Unpack and place all parts on surface or floor.

## **ASSEMBLY PROCEDURE:**

Attach the crossbar to the ceiling outlet box using the two screws provided with the outlet box. Note: If the screws with the outlet box are too short, use the (2) 5-32x 1-1/4" screws provided in the mounting hardware package. Next, screw the screw collar loop onto the nipple and then screw the nipple into the crossbar.

Attach one end of the chain onto the screw collar loop and then attach the other end of the chain onto the fixture loop on the top of the fixture.

Insert the fixture wire and the ground wire up through the nipple. Connect the white or ribbed fixture wire to the white supply wire in the outlet box using the twist-on wire connectors provided. Connect the black or smooth fixture wire to the black supply wire in the same manner. Install the fixture ground wire under the green ground screw on the crossbar then connect the fixture ground wire to the supply ground wire in the outlet box using the twist-on wire connector provided.

Tuck the wires carefully inside the outlet box. Spread the electrical splices so that the black wires are on one side of the outlet box and the white wires are on the other side. Next raise the canopy to the ceiling and secure in place by screwing the screw collar nut onto the screw collar loop.

Install bulb (maximum 60W type A, not included) into the socket.

