

BATTERY REPLACEMENT & INSTRUCTION SHEET

JINGLE PAWS | Lighted color changing garland. Musical, Plays: "Jingle Bells".

UNPACKING INSTRUCTIONS

- 1) Carefully unpack your figure.
- 2) Components may be wrapped separately.
- 3) Fabric and fur may need to be gently arranged or shaped after unpacking.
- 4) BATTERY COMPARTMENT: Located on bottom of dog house base.

BATTERY INSTALLATION

- 1) Open the Battery Compartment Cover.
- 2) Insert 3 AAA batteries into the battery compartment following the battery marking direction with correct polarity. (Alkaline Batteries Recommended.)
- 3) Close the Battery Cover.

BATTERY REPLACEMENT

If item does not function as intended, it may be due to low battery voltage.

Please follow the below steps to make battery replacement.

- 1) Open the Battery Compartment Cover.
- 2) Remove the old batteries from the battery compartment.
- 3) Insert 3 AAA batteries into the battery compartment following the battery marking direction with correct polarity. (Alkaline Batteries Recommended.)
- 4) Close the Battery Cover

To turn lights/music on, push the switch to the "II" position;

To turn lights on, no music, push the switch to the "I" position

Turn the off switch to "OFF" to extend the battery life.

BATTERY USAGE, HANDLING, AND DISPOSAL.

CAUTION: Incorrect use of batteries can result in hazards such as leakage and bursting.

Please observe the following:

- Risk of explosion if battery is replaced by an incorrect type.
- Dispose of used batteries according to the instructions.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries, or mix batteries with different brands, although they may look similar, different batteries may have different voltages.
- Make sure that the plus and minus ends of each battery match the indications in the battery compartment.
- Remove batteries from item that isn't going to be used for a month or more.
- Do not attempt to destroy or disassemble battery or remove any of its components.
- Batteries must be recycled or disposed of properly. Please consult your local waste authority for information regarding available recycling and/or disposal options/instructions.
- Keep batteries away from children and pets. Do not incinerate - fire and/or serious injury could result from a failure to comply with these warnings.
- Do not use or store batteries in direct sunlight or other excessively hot place, such as inside a car or near a heater. This can cause batteries to leak, overheat, explode or catch fire. It can also reduce the life or performance of batteries.



POSSIBLE DREAMS®
DEPARTMENT 

TOC20190802